


Interpact Switch-disconnectors INS/INV40 to 2500 A

The Interpact INS/INV switch-disconnectors perform control and disconnection of electrical distribution circuits in the tertiary and industrial sectors:

- Source coupling
- Local disconnection box
- Final distribution box
- Automation box
- Emergency stop switch

INS/INV Standard version with black handle - Fixed /FC

Part Number		Type	Nominal Current (A)	Description
3P	4P			
110114	110125	INS40	40	Switch-disconnectors with positive contact indication
110136	110147	INS63	63	
110158	110169	INS80	80	
110180	110191	INS100	100	
110202	110213	INS125	125	
110224	110235	INS160	160	
110246	110257	INV200	200	Switch-disconnectors with visible break
110268	110279	INV250	250	
110290	110301	INV320	320	
110312	110323	INV400	400	
110334	110345	INV500	500	
110356	110367	INV630	630	
110378	110389	INV630b	630	
110400	110411	INV800	800	
110422	110433	INV1000	1000	
110444	110455	INV1250	1250	
110466	110477	INV1600	1600	
110488	110499	INV2000	2000	
110510	110521	INV2500	2500	




INS Complete assembly source-changeover systems I - 0 - II

Part Number		Type	Nominal Current (A)	Description
3P	4P			
110532	110543	INS100	100	manual source-changeover switch with direct front rotary handle
110554	110565	INS160	160	
110576	110587	INS200	200	
110598	110609	INS250	250	
110620	110631	INS320	320	
110642	110653	INS400	400	
110664	110675	INS500	500	
110686	110697	INS630	630	



Interpact INS40 to INS160 connection accessories
• Bare cable connectors


Part Number	Description	For Disconnector	Package (pcs/pack)
110708	Snap-on	INS100 to INS160 S>95mm ²	3
110719			4
110730	Distribution connector for 4 rigid cables ≤ 25mm ² or 4 flexible cables ≤ 16mm ²	INS100 to INS160	3
110741			4


• Terminal shrouds

Part Number	For Disconnector	N° of poles	Package (pcs/pack)
110752	INS40 to INS80	3P/4P	2
110763	INS100 to INS160	3P/4P	2


• Terminal shields

Part Number	For Disconnector	N° of poles	Package (pcs/pack)
110774	INS40 to INS80	3P/4P	2
110785	INS100 to INS160	3P/4P	2


• Phase barriers

Part Number	For Disconnector	N° of poles	Package (pcs/pack)
110796	INS100 to INS160	3P/4P	6


Interpact INS40-INS160 electrical auxiliaries
• Auxiliary contacts

Part Number	Description	For Disconnector
110807	1 OF/CAF/CAO	INS100 to INS160
110818	1 OF/CAF/CAO (low level)	


Interpact INS40 to INS160 locks, interlocks & coupling accessories
• Handle locking

Part Number	Description
built-in	By 1 to 3 padlocks (OFF position), hasp dia. 5 to 8 mm or by lead seals



• Interlock for extended rotary handles

Part Number	Description
110829	Mechanical for INS40 to 160



Interpact INS40 to INS160 rotary handles
• Accessories for conversion to extended rotary handles

Part Number	Description	For Disconnector
110840	Front control with black handle	INS40 to 160
110851	Lateral control with black handle	


Interpact INS40 to INS160 spare parts
• Handle for rotary control

Part Number	Description	For Disconnector
110862	Front or lateral rotary control black handle	INS40 to 160


Interpact INV200 to INV630 connection accessories (Cu or Al)
• Rear connections

Part Number	Description	For Disconnector
110873	Short (1 pair)	INV200 to INV250
110884	Long (1 pair)	
110895	Short (1 pair)	INV320 to INV630
110906	Long (1 pair)	


• Bare cable connectors

Part Number	Description	For Disconnector	Package (pcs/pack)
110917	Steel,snap-on, for cables	INV200 to INV250	3
110928	1.5 to 95mm ² ≤160 A		4
110939	Aluminium,snap-on, for cables	INV200 to INV250	3
110950	25 to 95mm ² ≤250 A		4
110961	Aluminium,snap-on, for cables	INV320 to INV630	3
110972	120 to 185mm ² ≤250 A		4
110983	Distribution connector for six 1.5 to 35mm ² cables with phase barriers		3
110994	For 1 cable, 35mm ² to 300mm ²	INV320 to INV630	3
111005			4
111016	For 2 cables, 35mm ² to 240mm ²	INV320 to INV630	3
111027			4



• Crimp lugs for copper cables (supplied with 2 or 3 phase barriers)

Part Number	Description	For Disconnector	Package (pcs/pack)
111038	For cable 120mm ²	INV200 to INV250	3
111049	For cable 150mm ²		3
111060	For cable 185mm ²		3




(continue to next page)



Interpact INV200 to INV630 connection accessories (Cu or Al)
• Crimp lugs for copper cables (supplied with 2 or 3 phase barriers)
(continue from previous page)

Part Number	Description	For Disconnector	Package (pcs/pack)	
111071	For cable 240mm ²	INV320 to INV630	3	
111082	For cable 300mm ²		3	



• Crimp lugs for aluminium cables (supplied with 2 or 3 phase barriers)

Part Number	Description	For Disconnector	Package (pcs/pack)	
111093	For cable 150mm ²	INV200 to INV250	3	
111104	For cable 240mm ²	INV320 to INV630	3	

• Terminal extensions (supplied with 2 or 3 phase barriers)


Part Number	Description	For Disconnector	Package (pcs/pack)	
111115	Right-angle terminal extensions	INV200 to INV250	4	
111126	Straight terminal extensions		3	
111137			4	
111148	Right-angle terminal extensions	INV320 to INV630	4	
111159	Edgewise terminal extensions		3	
111170			4	

• Spreaders (for upstream or downstream connection)

Part Number	Description	For Disconnector	N° of poles	
111181	Separate for each pole, 45mm distance between poles	INV200 to INV250	3P	
111192			4P	
111203	Separate for each pole, 52.5mm distance between poles	INV320 to INV630	3P	
111214			4P	
111225	Separate for each pole, 70mm distance between poles		3P	
111236	Separate for each pole, 70mm distance between poles		4P	

Interpact INV200 to INV630 connection accessories (Cu or Al)
• Terminal shields


Part Number	Description	For Disconnector	N° of poles
111247	Short (1 pair)	INV200 to	3/4P
111258	Long (1 pair)	INV250	3/4P
111269	Short (1 pair)	INV320	3/4P
111280	Long (1 pair)		3/4P


Interpact INV200 to INV630 electrical auxiliaries
• Auxiliary contacts (changeover type)

Part Number	Description	For Disconnector
111291	OF or CAM (early make or break)	INV200 to INV630
111302	Low-level OF or CAM (early make or break)	


Interpact INV200 to INV630 rotary handles
• Extended front handles

Part Number	Description
111313	for INS250 with standard handle
111324	for INS250...630 / INV100...630
111335	for INS320/400/630 with standard handle


Interpact INV200 to INV630 Locks, interlocks & coupling accessories
• Locks

Part Number	Description	For Disconnector
built-in	By 1 to 3 padlocks (OFF position)	INV200 to INV630
111346	Locking device for Ronis/Profalux keylocks (without keylocks)	INV200 to INV250
111357	Keylock Ronis 1351B.500	
111368	Keylock Profalux KS5 B24 D4Z	
111379	Locking device for Ronis/Profalux keylocks (without keylocks)	INV320 to INV630
111390	Keylock Ronis 1351B.500	
111401	Keylock Profalux KS5 B24 D4Z	




(continue to next page)


Interpact INV200 to INV630 Locks, interlocks & coupling accessories
• Interlocks

(continue from previous page)


Part Number	Description	For Disconnector
111412	Mechanical	INV200 to INV250
111423	Mechanical	INV320 to INV630
111434	Locking device for Ronis/Profalux keylocks (without keylocks)	INV200 to INV250
111445		INV320 to INV630
111456	Keylock type (2 keylocks / 1 key) Ronis	INV200 to INV630
111467	Keylock type (2 keylocks / 1 key) Profalux	INV200 to INV630


Interpact INV630b to INV1600 connection accessories
• Vertical connection adapters


Part Number	Description	Poles	Package (pcs/pack)
111478	Vertical connection adaptors - for INV630b..1600	3P	3
111489		4P	4


• Cable lug adapters

Part Number	Description	Poles	Package (pcs/pack)
111500	Cable lug adapters - for INV630b..1600	3P	3
111511		4P	4


• Spreaders


Part Number	Description	Poles	Package (pcs/pack)
111522	Spreaders - for INV630b..1600	3P	3


• Base for terminal shield (not compatible with interphase barriers)


Part Number	Description	Poles	Package (pcs/pack)
111533	Base for terminal shield - for INV630b..1600	3P	1
111544		4P	1


• Terminal shields

Part Number	Description	Poles	Package (pcs/pack)
111555	Terminal shields - for INV630b..1600	3P	1
111566		4P	1


• Interphase barriers (not compatible with terminal shield and base)

Part Number	Description	Poles	Package (pcs/pack)
111577	Interphase barriers - for INV630b..1600	4P	6




Interpact INV200 to INV630 electrical auxiliaries
• Auxiliary contacts (changeover type)


Part Number	Description	For Disconnector
111588	OF or CAM (early make or break)	INV630b..1600
111599	OF or CAM low level (early make or break)	


Interpact INV200 to INV630 extended front control


Part Number	Description	For Disconnector
111610	extended front control	INV630b..1600


Interpact INV630b to INV1600 locking and interlocking
• Locking

Part Number	Description
built-in	Handle locking by 1 to 3 padlocks (in OFF position)
111621	Keylocking device - by keylock (2 pieces)
111632	Ronis 1351B.500 keylock
111643	Profalux KS5 B24 D4Z keylock


• Interlocking

Part Number	Description
111654	Keylocking device - by keylock (2 pieces)
111665	Ronis 1351B.500 keylock (1 keylocks / 1 key)
111676	Profalux KS5 B24 D4Z keylock (1 keylocks / 1 key)


Interpact INV630b to INV1600 installation accessories
• Escutcheon

Part Number	Description
111687	Escutcheon for INV630b..1600 - 3P/4P

